

01322 621700

**Texcel**  
**Technology**

Electronic  
Manufacturing  
Solutions

UK Based. UK Manufacture.  
Selling throughout the World.

**A Guide To Effective Stencil  
Design by Michael Keens**

[www.texceltechnology.com](http://www.texceltechnology.com) Enquiries: 01322 621 700

follow us



## Table of Contents

<b>Introduction</b>	<b>3</b>
<b>Considerations</b>	<b>3</b>
<i>Stencil thickness</i>	4
<i>Aperture Design</i>	5
<i>Stencil Material and Mounting</i>	6
<i>Alignment</i>	7
<i>PCB Design Specific</i>	8

## Introduction

One of the most important part of the surface mount assembly process is the application of solder paste to the printed circuit board (PCB) – this is generally achieved by the use of a stencil or foil.

A stencil is a thin sheet of material (typically stainless steel) with a series of apertures (holes) cut into it which suit the PCB to be printed.

The function of the solder paste stencil is to accurately deposit the correct amount of solder paste onto the surface mount pads so that the solder joint between PCB pad and component terminal are acceptable with regard to the electrical connection and mechanical strength.

## Considerations


The key design features of an effective solder paste stencil are as follows:-

- 1. Stencil thickness**
- 2. Aperture design**
- 3. Stencil material and mounting**
- 4. Alignment**
- 5. PCB design specific**

## 1. Stencil thickness

This is important to ensure there is good release of solder paste from the apertures and to obtain the correct volume of solder paste to achieve the desired solder joint. Typically the stencil thickness would be between 4 thou and 8 thou thick. If the stencil is too thick for the size of apertures then it can lead to the paste being held by surface tension to the inner walls of the aperture.

The following is a formula that can be used to select the appropriate stencil thickness:-





The release of solder paste from the apertures of the stencil is also affected by the particle size of the selected solder paste. Below are the particle sizes available:-

Particle size in microns	Particle type
75-45	2
45-25	3
38-20	4
25-15	5
15-5	6

There is a '5 ball rule' which says ideally a minimum of 5 solder particles should span the width of the smallest aperture.

## 2. Aperture design

This is important to stop solder defects from forming such as bridging and solder beads. Most apertures are designed to be slightly smaller than the pads (typically 2 thou reduction all round) to provide a good gasket seal between stencil and PCB but some apertures need a special design to deposit less paste on the inner edge of the part to reduce the possibility of 'mid-chip' solder balls forming. Below is an example of a possible solution known as 'home-plate' apertures and a photo of 'mid-chip' solder balls.



The design of the PCB pads also has a bearing on the resulting solder joints and so it is recommended that IPC standard IPC-SM-782 is referred to when defining surface mount pad dimensions.

### 3. Stencil material and mounting

The material type of the stencil will have an impact on its ability to release the solder paste from the apertures. Stainless steel is typically used but for PCB designs that have fine pitch devices a more expensive alternative (Nickel – approx. 50% more expensive than stainless steel) can be used. Other possibilities are to apply a coating to either material to further improve the release of paste from the apertures – An example of this is NanoProTek coating which is an additional fixed cost but does need to be re-applied periodically.

There are occasions where PCB designs contain a large variety of parts including fine pitch devices that require a thin stencil and larger parts that require a thicker stencil. In this case it is possible for a multilevel or 'stepped' stencil to be designed. Step-up areas are created by adding material to the stencil and are used to increase the volume and height of the solder paste in selected areas - Useful for 'pin in paste' and large format devices. Step-down areas are created by removing material from the stencil and are used to reduce the volume and height of the solder paste deposit in selected areas. In order to print successfully, apertures must be designed to be a minimum distance from the step edge. The distance is dependant on the step dimensions and is known as the 'keep out area'.




The method in which the stencil is manufactured can affect its ability to release paste from the apertures. The first generation of stencils were chemically etched which provides good results for larger apertures but as the size of components reduced the challenge of solder release from apertures increased. This prompted the introduction of laser-cut stencils which produced a much finer aperture that was trapezoidal in shape and so gave better paste release. Again, as component sizes reduced the option of electro-polishing the aperture walls was introduced and more recently the method of Electro-forming the stencil.

With respect to the stencil mounting, they can be either supplied permanently mounted to a frame or frameless. The permanently mounted stencils are better suited for high volume printing whereas the frameless stencils are less expensive and easier to store. The frameless stencils are designed to work with stencil tensioning systems known as reusable stencil frames – an example being Vectorguard.

#### 4. Alignment

In order to achieve an accurate print of the solder paste to the pads, good alignment of the stencil to the PCB is critical. This is achieved by adding registration marks known as fiducial marks to both the PCB and stencil. The addition of fiducial marks to the stencil will ensure good alignment is achieved as shown below.




Perfectly aligned solder paste on pads




## 5. PCB design specific

There can be occasions where components within the PCB design have large copper pads underneath the device, which as well as providing a secure electrical connection, are also used to dissipate heat from the device. If the area of the whole pad has solder paste applied it can result in the device lifting and the outer leads not soldering. This can be overcome by creating a 'window effect' in the stencil aperture design to reduce the solder volume as can be seen below.




Stencil with 'window effect'  
Aperture design




Resulting print of solder  
paste onto pads

Another PCB design feature on the same type of device that can cause undesirable results is when vias are included within the large copper pad to again dissipate heat from the device. In this case the stencil apertures can be specially designed to avoid the solder paste from being deposited onto the vias as can be seen below.



Stencil with specially designed  
Apertures to avoid vias



Resulting print of solder  
paste onto pads



## Conclusion

The printing stage of the assembly process is vitally important. If there are errors introduced at this stage there will be “knock on” effects throughout the process ultimately resulting in process failures. To achieve good repeatable printing results, it is important to use a stencil that is designed with all the appropriate points considered.

Most PCB's can be printed without needing to use a complex stencil design but there can be occasions where it is necessary to use many of the considerations discussed.

01322 621700

**Texcel**  
**Technology**

Electronic  
Manufacturing  
Solutions

[www.texceltechnology.com](http://www.texceltechnology.com) Enquiries: 01322 621 700

follow us

